



# Lighting lamp on a pole

Attractive pole finish, 12 V DC power supply.

An identical white light with a warning light function is also available. **yellow**



Insert the hexagonal key through the hole in the post into the screw socket and carefully turn the screw to the left until the lamp body is locked inside the post.



## 1. Key advantages:

- LED light source,
- 12 V DC power supply,
- Expansion, invisible top mounting, posts 100x100 mm, 80x100 mm, or 80x80 mm.

## 2. Lamp operation

Indicator light when connected to a 12 V DC power supply

It emits a constant white light. The lamp is designed to illuminate the perimeter fence. It is also possible to purchase a white light that, when connected to the gate drive, emits a warning yellow light – either constant or flashing.

## 3. Lamp installation

### Žibintas yra stačiakampio stulpo galas

100 x 100 mm, 80 x 100 mm, or 80 x 80 mm The lower 73 x 73 mm part of the luminaire must fit into the pole. Unscrew the hexagonal bolts as far as possible so that the lower part of the luminaire can be inserted into the pole with the bolts with minimal resistance. On the least visible side of the pole, drill a 4 mm diameter hole precisely along the extension of the hexagonal screw socket.

